




Billionaire Lighting Co.Ltd.


Installation Instructions




ScrewA		AX4
ScrewB		BX3
ScrewC		CX4
Hexagon driver		X1

1. Remove the packaging and take out all parts of the floor lamp.
2. Take out the lamp pole, and connect the terminal in the middle section of the pole according to Diagram A.
3. Assemble the lamp pole by following the steps shown in Diagram B.


1. Secure the lamp pole using screw B and the hex key, as shown in the diagram.




1. Remove the base and ensure it is stabilized to prevent tipping.
2. Insert the lamp pole into the base's fixed position as shown in Diagram A.
3. Secure the pole to the base using screw C and the hex key, following Diagram B.




1. Connect the terminal of the lamp head cable to the terminal of the upper lamp pole, as shown in Diagram A.
2. Attach the lamp pole to the lamp head, following the instructions in Diagram B.



1. Take screw A from the accessory bag and use the hex key to secure the lamp head to the pole, as shown in Diagram A.



1. Insert the cable into the socket on the lamp pole as shown in Diagram A, and ensure it is securely connected.



⚠ WARNING! Improper power connection.
Risk of electric shock, which may lead to fatal injury.
◆Ensure the power supply is properly grounded.

⚠ WARNING! Exposed electrical parts.
Electric shock hazard may cause fatal injury.
◆Assemble luminaire completely before power connection.
NOTE: Wrong voltage may damage the luminaire.
◆Confirm supply voltage and frequency match luminaire ratings.

Connect the plug to the power outlet.