





Billionaire Lighting Co., Ltd.

Installation Instructions




Accessory


Screw A		AX4
Screw B		BX4
Screw C		CX2
Cross point screwdriver		X1
Hexagon screwdriver		X1




Fix the light pole 1 to the base with screw A




Connect the terminal of the lamp pole with the metal connector and the terminal of the lamp head together




Put the connected terminal into the lamp pole and put the lamp pole into the lamp head




Fix the lamp pole inserted into the lamp head with screw B




Splice the terminals of the connecting parts of the two light poles together, and insert the connected terminals into the light pole 1



Connect the two poles together, and align the screw fixing holes



Use screw C to connect and fix the two poles together. Before fixing, you can adjust the angle of the touch panel of pole 1 and pole 2



Insert the tail of the AC cable into the terminal seat of lamp pole. The other end is connected to the AC input